
# **ASSEMBLY INSTRUCTIONS**



## Goodman Table Lamp

Item # TOB3536

### INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

### ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

- Carefully remove all parts from the carton.
- Carefully put the finial (D) onto the switch knob (C) on top of the shade.
- Insert light bulb into socket.
  Remove plastic cover (F) from electrical plug (E).
- 5. Plug lamp into wall outlet.

### ADJUSTMENT INSTRUCTION

- 1. Loosen adjustment key (B).
- 2. Adjust lamp by swing lamp arm (A) or lamp shade to desired position. 3. Tighten the adjustment key (B).

\*\*\*Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.







